



FEEL NOIR
elementi satinati su base lucida
satin elements on a polished base



FEEL CHOCOLAT
elementi satinati su base lucida
satin elements on a polished base




FEEL EUPHORIA
elementi lucidi su base lucida
polished elements on a polished base



FEEL TECHNO
elementi lucidi su base satinata
polished elements on a satin base



FEEL DESERT
elementi lucidi su base satinata
polished elements on a satin base



FEEL ABSOLUTE
elementi lucidi su base satinata
polished elements on a satin base

MISURE (cm) Size	80	Design Fabrizio Crisà
FINITURE Finish	VETRO LUCIDO E SATINATO + COLORI Polished and satin glass + colours	(Elica Design Center)

FEEL

PARETE

WALL MOUNTED

Comandi Controls	E-motion E-motion
Illuminazione Lighting	Led 12W Led 12W
Versione Version	Filtrante Recycling
N. Motori No. of motors	1
Uscita (mm) Duct Size	150
Portata IEC (m³/h) IEC airflow	260-700
Livello Sonoro db(A) Noise Level	44-64
Pressione (Pa) Pressure	460
Assorbimento (W) Absorption	262




ACCESSORI Accessories	CODICE Code
Filtro Grassi Grease Filter	GFA Incluso GFA Included
Filtro Carbone Charcoal Filter	Incluso Included
Filtro Lunga Durata Long Life Filter	Non disponibile Not available
Kit camino (h450-450) Chimney Kit (h450-450)	A richiesta Optional
Kit camino (h220-270) Chimney Kit (h220-270)	A richiesta Optional

MODELLO Models		
FEEL ABSOLUTE	F/80	PRF0020287
FEEL NOIR	F/80	PRF0020288
FEEL DESERT	F/80	PRF0020289
FEEL EUPHORIA	F/80	PRF0020290
FEEL TECHNO	F/80	PRF0020801
FEEL CHOCOLAT	F/80	PRF0020802

Disponibile a partire da Luglio 2011
Available from July 2011



Feel Euphoria



Dotata di e-motion, un sistema di controllo naturale e intuitivo. Il controllo delle funzioni avviene sfiorando i pannelli che si attivano con un movimento elettronico. Per cotture a basso contenuto di vapori, sarà sufficiente aprire il pannello più piccolo; per una più ampia capacità di aspirazione sarà necessario aprire quello più grande. Per una cottura intensa, è opportuno aprire entrambi i pannelli contemporaneamente. Allo stesso modo, lo sfioramento del pannello orizzontale attiverà l'illuminazione del piano cottura.

With e-motion, the natural and intuitive control system. Simply touch the electronically activated panels to operate them. Open the smaller panel when your cooking produces only a little steam. Open the larger panel if you need to extract more steam. When your cooking produces a lot of steam, open both panels together. Touching the horizontal panel switches the hob lighting on and off.

e-motion

Feel Noir



Feel Chocolat



Feel Techno



Feel Desert



Feel Absolute